

GUIDANCE DOCUMENT

Passive PE Sampling in Support of In Situ Remediation of Contaminated Sediments: Standard Operating Procedure for PE Analysis

ESTCP Project ER-200915

December 2012

Philip Gschwend
John MacFarlane
MIT

Kevin Palaia
Steve Reichenbacher
Dean Gouveia
ICF International

This document has been cleared for public release



REPORT DOCUMENTATION PAGE				<i>Form Approved</i> <i>OMB No. 0704-0188</i>	
The public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing the burden, to the Department of Defense, Executive Services and Communications Directorate (0704-0188). Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ORGANIZATION.					
1. REPORT DATE (DD-MM-YYYY) 12-2012		2. REPORT TYPE Guidance Document		3. DATES COVERED (From - To) 12-2008-12-2012	
4. TITLE AND SUBTITLE Passive PE Sampling in Support of In Situ Remediation of Contaminated Sediments (Standard Operating Procedure for the Extraction and Analysis of Polyethylene Used in Polyethylene Devices)				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S) Philip Gschwend John MacFarlane Kevin Palaia Steve Reichenbacher Dean Gouveia				5d. PROJECT NUMBER ER-200915	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Massachusetts Institute of Technology 15 Vassar St., Bld 48, Rm 413 Cambridge, MA 02139				8. PERFORMING ORGANIZATION REPORT NUMBER ER-200915	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) SERDP/ESTCP 4800 Mark Center Drive, Suite 17D08 Alexandria, VA 22350-3605				10. SPONSOR/MONITOR'S ACRONYM(S) SERDP/ESTCP	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Unlimited					
13. SUPPLEMENTARY NOTES					
14. ABSTRACT This method describes procedures for chemical analysis of contaminants contained in polyethylene (PE) that has been deployed in polyethylene devices (PEDs) to sample hydrophobic organic compounds (HOCs) in aquatic and sediment environments.					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF: a. REPORT b. ABSTRACT c. THIS PAGE			17. LIMITATION OF ABSTRACT		18. NUMBER OF PAGES 6
					19a. NAME OF RESPONSIBLE PERSON Carmen Lebron
					19b. TELEPHONE NUMBER (Include area code) 617-253-1638

Reset

**Standard Operating Procedure
for the Extraction and Analysis of Polyethylene (PE) Used
in Polyethylene Devices (PEDs)**

1.0 SCOPE AND APPLICATION

- 1.1 This method describes procedures for chemical analysis of contaminants contained in polyethylene (PE) that has been deployed in polyethylene devices (PEDs) to sample hydrophobic organic compounds (HOCs) in aquatic and sediment environments.
- 1.2 This procedure generates extracts suitable for High Resolution Gas Chromatography/Mass Spectrometry (GCMS) analysis.
- 1.3 This extraction procedure is applicable to PE used in laboratory- or field-exposed PEDs.

2.0 SUMMARY OF METHOD

- 2.1 Upon recovery from the field exposure, the PE, while still in the PED, should be carefully cleaned (e.g. remove adhering sediment) and then cut into appropriate lengths (e.g., to obtain replicates or to acquire sections exposed to varying depths into a sediment bed). The PE pieces, usually 10 to 100 milligram quantities, are placed in pre-cleaned, amber, glass vials with a drop of water for shipping. Once received by the analytical laboratory, each sample is spiked with Surrogate standards (to assess analyte recoveries) and submerged in a suitable solvent (e.g., methylene chloride) for at least 12 hours. The extract is transferred to a large vessel suited for solvent evaporation, and then the PE is re-extracted three more times with methylene chloride, with the extracts combined for evaporative concentration and eventual GCMS (or suitable) instrumental analysis. After extraction, the PE is air-dried and weighed.
- 2.2 A shaker table or some other suitable mechanical agitation is recommended for the extractions to facilitate PE-solvent contact.

3.0 INTERFERENCES

- 3.1 PE is susceptible to contamination from atmospheric and surfaces, and so it must be handled using clean techniques.
- 3.2 While the formation of biofilms and epiphytic growth on PE surfaces does not compromise their behavior in the field during deployment, these coatings can substantially complicate subsequent chemical analysis. Careful removal of adhering sediment or surface growths via water-wetted Kimwipe[®] wiping may be necessary. Surface coatings of organic films on PE (e.g., oil or tar residues) can be removed by using solvent-saturated wipes (<minute contact times) followed by immediate Surrogate standard addition and solvent extraction.

4.0 APPARATUS AND MATERIALS

- 4.1 Extraction vessels: amber glass vials (foil-lined lids)
- 4.2 Concentrating vessels: 100 mL glass, pear-shaped flask with glass stopper; 250 mL glass, round-bottom flask with glass stopper or equivalent
- 4.3 Bottle/jar tumbler, shaker table, bottle roller or equivalent
- 4.4 Analytical balance - capable of weighing to 0.1 mg (i.e., small value relative to samplers weights that are typically between 10 and 100 mg.)
- 4.5 Food-grade aluminum foil
- 4.6 Stainless steel forceps
- 4.7 Single-edge razor blades
- 4.8 Teflon (or similar non-contaminating material) cutting board
- 4.9 Glass transfer pipettes.
- 4.10 Kimberly-Clark Kimwipe® or equivalent

5.0 REAGENTS

- 5.1 Methylene chloride, CH₂Cl₂, pesticide grad or equivalent (other solvent suited to analytes of interest).
- 5.2 Organic-free reagent water (as defined in SW-846 Chapter One)
- 5.3 Research grade surrogate and injection standard compounds certified >98+% pure or equivalent.

6.0 PREPARATION AND HANDLING

- 6.1 Upon recovery and return to a clean working environment, the PE should be surface cleaned prior to any cutting or extraction. The PE surface should be wiped and rinsed free of surface particles and coatings. This may include briefly (< minute) wiping with a hexane-soaked Kimwipe® (or equivalent) to remove oily or tarry exterior staining. If water wet, the PE surface should be blotted dry with a clean wipe.
- 6.2 Laboratory and field personnel should wear nitrile or latex gloves whenever handling PE to avoid cross-contaminating the PE.
- 6.3 Methylene chloride (pesticide grade) rinsed, stainless steel forceps and scissors are used when manipulation of PE is required.
- 6.4 Clean aluminum foil is used to cover any surface that PE may encounter.

7.0 PROCEDURE

- 7.1 Solvent Extraction: Laboratory and/or field blank and field-exposed PE is spiked with known quantities of surrogate compounds to assess analytical recoveries and extracted using organic solvents prior to analysis by GC/MS.
 - 7.1.1 The PE is inspected for surface biofilms, particles, mud, or oily coatings. Biofilm mass should be removed by using a clean wipe followed by a rinse with organic-

free reagent water. Particles and sedimentary debris are removed by rinsing with organic-free reagent water and careful surface scraping if necessary to remove adhered/imbedded material. Oily coatings (e.g., coal tar staining or hydrocarbon slicks) are removed by soaking clean wipes in hexane and using forceps to hold and wipe both PE surfaces. This is not an exhaustive extraction and should be done quickly (<minute) and immediately prior to immersion in solvent. PE surfaces are blotted dry if water wet.

- 7.1.2 The PE is transferred to a pre-cleaned amber vial (size determined by dimensions of PE, typically 15-40mL). Vial must be large enough for complete immersion of PE without excessive PE folding.
 - 7.1.3 Known masses of surrogate compounds (Appendix 1) in a methylene chloride-compatible solvent are added to the vial. Typical additions are: 2.5-20 ng for aqueous samples; 50-250 ng for sediment samples, depending on target HOCs and their expected concentrations in the PE.
 - 7.1.4 Methylene chloride is added to the vial to completely submerge the PE for a period of at least 12 hours.
 - 7.1.5 The extract is transferred to a pre-cleaned glass concentration vessel. A second aliquot of methylene chloride is added to the extraction vial and agitated for >10 minutes. This step is repeated two more times.
 - 7.1.6 After the final extract transfer, the PE is allowed to air dry in the extraction vial and weighed on an analytical balance until a consistent PE mass is obtained. This result is used to calculate the final target HOC concentrations measured in the PE sampler in units of HOC mass per PE mass.
- 7.2 Extracts are concentrated using rotary evaporation (or equivalent) down to suitable volumes for GCMS analysis; the resultant concentrated extracts are transferred to smaller vials (e.g., for autosamplers) according to standard laboratory practices. Before analysis, appropriate injection standards are added to the final extracts to allow for evaluation of the total volume of extract analyzed (Appendix 1).

Typical final extract volumes are:

50-250 µL for water column-exposed PE

1-10 mL for contaminated sediment bed-exposed PE

8.0 QUALITY CONTROL

- 8.1 Method blanks, field blanks, matrix spikes, and/or replicate samples should be subjected to exactly the same analytical procedures as those used on field/lab-exposed samples.
- 8.2 QA/QC metrics, that are specific to the type of target HOCs of interest and the analytical methods used to quantify them, should be applied. Typical values for targets like PAHs and PCBs that are analyzed by capillary gas chromatography-low resolution mass spectrometry, in which picogram/µL detection is common, are:

8.2.1 Freshly prepared polyethylene and trip blanks:

<0.1 ng / g PE

Freshly cleaned PE samples, and samples of PE that traveled to and from the field site ("trip blank"), should have no significant peaks where PRCs, surrogate standards, injection standards, and target analytes elute.

- 8.2.2 PRC-loaded polyethylene reproducibility ($\pm 1\sigma$ /mean, N=6): <10%
Individual batches of PE loaded with PRCs should exhibit reproducible PRC concentrations in the PE before deployment.
- 8.2.3 Recoveries of Surrogate Standards: >70% to < 120%
Surrogate standards should be recovered from PE samples at 100%, plus or minus analytical precision. An exception may be relatively volatile compounds (e.g., mono-, di-chlorobiphenyls) that may be significantly lost when extracts are evaporated (e.g., recovery down to 60%).
- 8.2.4 Precision of replicate PE extract analyses (N \geq 3): <20%.
The reproducibility of all analytes (injection standards, surrogate standards, PRCs, and target compounds) determined with multiple instrumental analyses of the same PE sample extract, even run on different dates, should fall with suitably narrow bounds.
- 8.2.5 Detection limits using PE samples: <1 ng / g PE
Assuming 100 mg PE samples and 100 uL final extract volumes, target analytes such as PAHs and PCBs analyzed by GCMS (or methods with like sensitivity) should have <ppb detection limits.

9.0 METHOD PERFORMANCE

- 9.1 The method performance is assessed by determining the recovery and reproducibility in analyzing surrogate compounds (Appendix 1). All other lab-specific QA/QC metrics should be adhered to.
- 9.2 Successful PE deployment is achieved when significant (>method precision) losses of PRCs occurred, allowing one to use their behavior to adjust target compound levels in the PE up to equilibrium concentrations (Fernandez et al. 2009).

10.0 REFERENCES

Fernandez L.A., Harvey, C.F., and Gschwend, P.M. Using performance reference compounds in polyethylene passive samplers to deduce sediment pore water concentrations for numerous target chemicals. Environ. Sci. Technol., 43, 8888-8894, 2009.

Appendix 1 Suggested Performance Reference Compounds (PRCs), Surrogate Compounds (Recovery Standards), and Injection Standards. The lab preparing the PEDs must coordinate PRC choices with the lab doing the PE analyses to avoid conflicting uses.

A. PRCs, suitable for polycyclic aromatic hydrocarbon (PAH) determinations when Capillary Gas Chromatography-Mass Spectrometry (GCMS) is used for analysis include, but are not restricted to, deuterated PAHs. One subset should be used as PRCs, while reserving others for use as surrogate (recovery) and injection standards. Unlabeled compounds such as terphenyl can be used as injection standards if they are readily resolved from the other analytes.

Targets: PAHs	Method: GCMS	Detection Limit ~ 100 pg / 100 mg PE	
PRCs	d10-phenanthrene	d10-pyrene	d12-chrysene
Surrogates	d10-anthracene	d10-fluoranthene	d12-benz(a)anthracene
Injection Standards	d10-acenaphthene	d14- <i>m</i> -terphenyl	d12-perylene

B. PRCs and surrogate compounds suitable for polychlorinated biphenyl (PCB) determinations when GCMS is the method separation and detection include, but are not restricted to, ¹³C-labeled or deuterated PCB congeners. One subset, for example including tri-, tetra-, penta-, hexa-, and heptachloro-biphenyls, can be used as PRCs while reserving different tri-, tetra-, penta-, hexa-, and heptachloro-biphenyl congeners to serve as surrogate compounds. Still other compounds such as deuterated PAHs or rare PCBs (not contained in Aroclor/Clophan mixtures such as: PCB-39, PCB-55, PCB-104, PCB-150 and PCB-188) can be used as injection standards.

Targets: PCBs	Method: GCMS	Detection Limit ~ 100 pg / 100 mg PE				
PRCs	¹³ C PCB-28	¹³ C PCB-52	¹³ C PCB-101	¹³ C PCB-153	¹³ C PCB-180	
Surrogates	¹³ C PCB-19	d ₆ PCB-77	¹³ C PCB-105	¹³ C PCB-167	¹³ C PCB-170	¹³ C PCB-194
Injection Standards	d17-39	d22-104	d34-55	d40-150	d52-188	

C. When analyzing for organochlorine pesticides such as DDT using GCMS, ¹³C labeled compounds can serve as PRCs. However, since DDT has been seen to degrade to form DDE or DDD in certain situations, one should use the 4,4'- isomer of DDT and the 2,4'-isomers of DDE and DDD as PRCs to allow appearance of ¹³C-labelled 4,4'-DDE or 4,4'-DDD to be interpreted as arising from reaction the DDT PRC during the deployment. Deuterated or ¹³C labeled PCBs can be used as surrogate (recovery) and injection standards.

Targets: DDTs	Method: GCMS	Detection Limit ~ 200 pg / 100 mg PE	
PRCs	¹³ C 2,4'-DDE	¹³ C 2,4'-DDD	¹³ C 4,4'-DDT
Surrogates	¹³ C-PCB111	¹³ C-PCB153	¹³ C PCB 178
Injection Standards	d6 PCB 77	¹³ C PCB 105	¹³ C PCB 167